

# Spur Gears

1. Introduction.
2. Friction Wheels.
3. Advantages and Disadvantages of Gear Drives.
4. Classification of Gears.
5. Terms used in Gears.
6. Condition for Constant Velocity Ratio of Gears—Law of Gearing.
7. Forms of Teeth.
8. Cycloidal Teeth.
9. Involute Teeth.
10. Comparison Between Involute and Cycloidal Gears.
11. Systems of Gear Teeth.
12. Standard Proportions of Gear Systems.
13. Interference in Involute Gears.
14. Minimum Number of Teeth on the Pinion in order to Avoid Interference.
15. Gear Materials.
16. Design Considerations for a Gear Drive.
17. Beam Strength of Gear Teeth—Lewis Equation.
18. Permissible Working Stress for Gear Teeth in Lewis Equation.
19. Dynamic Tooth Load.
20. Static Tooth Load.
21. Wear Tooth Load.
22. Causes of Gear Tooth Failure.
23. Design Procedure for Spur Gears.
24. Spur Gear Construction.
25. Design of Shaft for Spur Gears.
26. Design of Arms for Spur Gears.



## 28.1 Introduction

We have discussed earlier that the slipping of a belt or rope is a common phenomenon, in the transmission of motion or power between two shafts. The effect of slipping is to reduce the velocity ratio of the system. In precision machines, in which a definite velocity ratio is of importance (as in watch mechanism), the only positive drive is by **gears** or **toothed wheels**. A gear drive is also provided, when the distance between the driver and the follower is very small.

## 28.2 Friction Wheels

The motion and power transmitted by gears is kinematically equivalent to that transmitted by frictional wheels or discs. In order to understand how the motion can be transmitted by two toothed wheels, consider two plain circular wheels *A* and *B* mounted on shafts. The wheels have sufficient rough surfaces and press against each other as shown in Fig. 28.1.




Fig. 28.1. Friction wheels.




Fig. 28.2. Gear or toothed wheel.

Let the wheel A is keyed to the rotating shaft and the wheel B to the shaft to be rotated. A little consideration will show that when the wheel A is rotated by a rotating shaft, it will rotate the wheel B in the opposite direction as shown in Fig. 28.1. The wheel B will be rotated by the wheel A so long as the tangential force exerted by the wheel A does not exceed the maximum frictional resistance between the two wheels. But when the tangential force ( $P$ ) exceeds the \*frictional resistance ( $F$ ), slipping will take place between the two wheels.

In order to avoid the slipping, a number of projections (called teeth) as shown in Fig. 28.2 are provided on the periphery of the wheel A which will fit into the corresponding recesses on the periphery of the wheel B. A friction wheel with the teeth cut on it is known as **gear** or **toothed wheel**. The usual connection to show the toothed wheels is by their pitch circles.

**Note :** Kinematically, the friction wheels running without slip and toothed gearing are identical. But due to the possibility of slipping of wheels, the friction wheels can only be used for transmission of small powers.

### 28.3 Advantages and Disadvantages of Gear Drives

The following are the advantages and disadvantages of the gear drive as compared to other drives, *i.e.* belt, rope and chain drives :

#### Advantages

1. It transmits exact velocity ratio.
2. It may be used to transmit large power.
3. It may be used for small centre distances of shafts.
4. It has high efficiency.
5. It has reliable service.
6. It has compact layout.

#### Disadvantages

1. Since the manufacture of gears require special tools and equipment, therefore it is costlier than other drives.



In bicycle gears are used to transmit motion. Mechanical advantage can be changed by changing gears.

\* We know that frictional resistance,  $F = \mu \cdot R_N$

where  $\mu$  = Coefficient of friction between the rubbing surfaces of the two wheels, and  $R_N$  = Normal reaction between the two rubbing surfaces.

2. The error in cutting teeth may cause vibrations and noise during operation.
3. It requires suitable lubricant and reliable method of applying it, for the proper operation of gear drives.

### 28.4 Classification of Gears

The gears or toothed wheels may be classified as follows :

1. **According to the position of axes of the shafts.** The axes of the two shafts between which the motion is to be transmitted, may be

(a) Parallel, (b) Intersecting, and (c) Non-intersecting and non-parallel.

The two parallel and co-planar shafts connected by the gears is shown in Fig. 28.2. These gears are called **spur gears** and the arrangement is known as **spur gearing**. These gears have teeth parallel to the axis of the wheel as shown in Fig. 28.2. Another name given to the spur gearing is **helical gearing**, in which the teeth are inclined to the axis. The **single** and **double helical gears** connecting parallel shafts are shown in Fig. 28.3 (a) and (b) respectively. The object of the double helical gear is to balance out the end thrusts that are induced in single helical gears when transmitting load. The double helical gears are known as **herringbone gears**. A pair of spur gears are kinematically equivalent to a pair of cylindrical discs, keyed to a parallel shaft having line contact.

The two non-parallel or intersecting, but coplaner shafts connected by gears is shown in Fig. 28.3 (c). These gears are called **bevel gears** and the arrangement is known as **bevel gearing**. The **bevel gears**, like spur gears may also have their teeth inclined to the face of the bevel, in which case they are known as **helical bevel gears**.




Fig. 28.3

The two non-intersecting and non-parallel *i.e.* non-coplanar shafts connected by gears is shown in Fig. 28.3 (d). These gears are called **skew bevel gears** or **spiral gears** and the arrangement is known as **skew bevel gearing** or **spiral gearing**. This type of gearing also have a line contact, the rotation of which about the axes generates the two pitch surfaces known as **hyperboloids**.

**Notes :** (i) When equal bevel gears (having equal teeth) connect two shafts whose axes are mutually perpendicular, then the bevel gears are known as **mitres**.

(ii) A hyperboloid is the solid formed by revolving a straight line about an axis (not in the same plane), such that every point on the line remains at a constant distance from the axis.

(iii) The worm gearing is essentially a form of spiral gearing in which the shafts are usually at right angles.

2. **According to the peripheral velocity of the gears.** The gears, according to the peripheral velocity of the gears, may be classified as :

(a) Low velocity, (b) Medium velocity, and (c) High velocity.

The gears having velocity less than 3 m/s are termed as *low velocity gears* and gears having velocity between 3 and 15 m/s are known as *medium velocity gears*. If the velocity of gears is more than 15 m/s, then these are called *high speed gears*.

3. *According to the type of gearing.* The gears, according to the type of gearing, may be classified as :

- (a) External gearing, (b) Internal gearing, and (c) Rack and pinion.




Fig. 28.4

In *external gearing*, the gears of the two shafts mesh externally with each other as shown in Fig. 28.4 (a). The larger of these two wheels is called *spur wheel* or *gear* and the smaller wheel is called *pinion*. In an external gearing, the motion of the two wheels is always unlike, as shown in Fig. 28.4 (a).

In *internal gearing*, the gears of the two shafts mesh internally with each other as shown in Fig. 28.4 (b). The larger of these two wheels is called *annular wheel* and the smaller wheel is called *pinion*. In an internal gearing, the motion of the wheels is always like as shown in Fig. 28.4 (b).

Sometimes, the gear of a shaft meshes externally and internally with the gears in a straight line, as shown in Fig. 28.5. Such a type of gear is called *rack* and *pinion*. The straight line gear is called *rack* and the circular wheel is called *pinion*. A little consideration will show that with the help of a rack and pinion, we can convert linear motion into rotary motion and *vice-versa* as shown in Fig. 28.5.

4. *According to the position of teeth on the gear surface.* The teeth on the gear surface may be

- (a) Straight, (b) Inclined, and (c) Curved.

We have discussed earlier that the spur gears have straight teeth whereas helical gears have their teeth inclined to the wheel rim. In case of spiral gears, the teeth are curved over the rim surface.




Fig. 28.5. Rack and pinion.

### 28.5 Terms used in Gears

The following terms, which will be mostly used in this chapter, should be clearly understood at this stage. These terms are illustrated in Fig. 28.6.

1. *Pitch circle.* It is an imaginary circle which by pure rolling action, would give the same motion as the actual gear.

\* A straight line may also be defined as a wheel of infinite radius.

**2. Pitch circle diameter.** It is the diameter of the pitch circle. The size of the gear is usually specified by the pitch circle diameter. It is also called as *pitch diameter*.

**3. Pitch point.** It is a common point of contact between two pitch circles.

**4. Pitch surface.** It is the surface of the rolling discs which the meshing gears have replaced at the pitch circle.

**5. Pressure angle or angle of obliquity.** It is the angle between the common normal to two gear teeth at the point of contact and the common tangent at the pitch point. It is usually denoted by  $\phi$ . The standard pressure angles are  $14\frac{1}{2}^\circ$  and  $20^\circ$ .

**6. Addendum.** It is the radial distance of a tooth from the pitch circle to the top of the tooth.

**7. Dedendum.** It is the radial distance of a tooth from the pitch circle to the bottom of the tooth.

**8. Addendum circle.** It is the circle drawn through the top of the teeth and is concentric with the pitch circle.

**9. Dedendum circle.** It is the circle drawn through the bottom of the teeth. It is also called **root circle**.

**Note :** Root circle diameter = Pitch circle diameter  $\times \cos \phi$ , where  $\phi$  is the pressure angle.

**10. Circular pitch.** It is the distance measured on the circumference of the pitch circle from a point of one tooth to the corresponding point on the next tooth. It is usually denoted by  $p_c$ . Mathematically,

$$\text{Circular pitch, } p_c = \pi D/T$$

where

$D$  = Diameter of the pitch circle, and

$T$  = Number of teeth on the wheel.

A little consideration will show that the two gears will mesh together correctly, if the two wheels have the same circular pitch.

**Note :** If  $D_1$  and  $D_2$  are the diameters of the two meshing gears having the teeth  $T_1$  and  $T_2$  respectively; then for them to mesh correctly,

$$p_c = \frac{\pi D_1}{T_1} = \frac{\pi D_2}{T_2} \text{ or } \frac{D_1}{D_2} = \frac{T_1}{T_2}$$




Fig. 28.6. Terms used in gears.



Spur gears

**11. Diametral pitch.** It is the ratio of number of teeth to the pitch circle diameter in millimetres. It denoted by  $p_d$ . Mathematically,

$$\text{Diametral pitch, } p_d = \frac{T}{D} = \frac{\pi}{p_c} \quad \left( \because p_c = \frac{\pi D}{T} \right)$$

where

$T$  = Number of teeth, and

$D$  = Pitch circle diameter.

**12. Module.** It is the ratio of the pitch circle diameter in millimetres to the number of teeth. It is usually denoted by  $m$ . Mathematically,

$$\text{Module, } m = D / T$$

**Note :** The recommended series of modules in Indian Standard are 1, 1.25, 1.5, 2, 2.5, 3, 4, 5, 6, 8, 10, 12, 16, 20, 25, 32, 40 and 50.

The modules 1.125, 1.375, 1.75, 2.25, 2.75, 3.5, 4.5, 5.5, 7, 9, 11, 14, 18, 22, 28, 36 and 45 are of second choice.

**13. Clearance.** It is the radial distance from the top of the tooth to the bottom of the tooth, in a meshing gear. A circle passing through the top of the meshing gear is known as **clearance circle**.

**14. Total depth.** It is the radial distance between the addendum and the dedendum circle of a gear. It is equal to the sum of the addendum and dedendum.

**15. Working depth.** It is radial distance from the addendum circle to the clearance circle. It is equal to the sum of the addendum of the two meshing gears.

**16. Tooth thickness.** It is the width of the tooth measured along the pitch circle.

**17. Tooth space.** It is the width of space between the two adjacent teeth measured along the pitch circle.

**18. Backlash.** It is the difference between the tooth space and the tooth thickness, as measured on the pitch circle.



- 19. Face of the tooth.** It is surface of the tooth above the pitch surface.
  - 20. Top land.** It is the surface of the top of the tooth.
  - 21. Flank of the tooth.** It is the surface of the tooth below the pitch surface.
  - 22. Face width.** It is the width of the gear tooth measured parallel to its axis.
  - 23. Profile.** It is the curve formed by the face and flank of the tooth.
  - 24. Fillet radius.** It is the radius that connects the root circle to the profile of the tooth.
  - 25. Path of contact.** It is the path traced by the point of contact of two teeth from the beginning to the end of engagement.
  - 26. Length of the path of contact.** It is the length of the common normal cut-off by the addendum circles of the wheel and pinion.
  - 27. Arc of contact.** It is the path traced by a point on the pitch circle from the beginning to the end of engagement of a given pair of teeth. The arc of contact consists of two parts, *i.e.*
    - (a) Arc of approach.** It is the portion of the path of contact from the beginning of the engagement to the pitch point.
    - (b) Arc of recess.** It is the portion of the path of contact from the pitch point to the end of the engagement of a pair of teeth.
- Note :** The ratio of the length of arc of contact to the circular pitch is known as **contact ratio** *i.e.* number of pairs of teeth in contact.

### 28.6 Condition for Constant Velocity Ratio of Gears—Law of Gearing

Consider the portions of the two teeth, one on the wheel 1 (or pinion) and the other on the wheel 2, as shown by thick line curves in Fig. 28.7. Let the two teeth come in contact at point  $Q$ , and the wheels rotate in the directions as shown in the figure.

Let  $TT$  be the common tangent and  $MN$  be the common normal to the curves at point of contact  $Q$ . From the centres  $O_1$  and  $O_2$ , draw  $O_1M$  and  $O_2N$  perpendicular to  $MN$ . A little consideration will show that the point  $Q$  moves in the direction  $QC$ , when considered as a point on wheel 1, and in the direction  $QD$  when considered as a point on wheel 2.

Let  $v_1$  and  $v_2$  be the velocities of the point  $Q$  on the wheels 1 and 2 respectively. If the teeth are to remain in contact, then the components of these velocities along the common normal  $MN$  must be equal.

$$\begin{aligned} \therefore v_1 \cos \alpha &= v_2 \cos \beta \\ \text{or } (\omega_1 \times O_1Q) \cos \alpha &= (\omega_2 \times O_2Q) \cos \beta \\ (\omega_1 \times O_1Q) \frac{O_1M}{O_1Q} &= (\omega_2 \times O_2Q) \frac{O_2N}{O_2Q} \\ \therefore \omega_1 \cdot O_1M &= \omega_2 \cdot O_2N \\ \text{or } \frac{\omega_1}{\omega_2} &= \frac{O_2N}{O_1M} \quad \dots(i) \end{aligned}$$


Also from similar triangles  $O_1MP$  and  $O_2NP$ ,

$$\frac{O_2N}{O_1M} = \frac{O_2P}{O_1P} \quad \dots(ii)$$

Combining equations (i) and (ii), we have

$$\frac{\omega_1}{\omega_2} = \frac{O_2P}{O_1P} = \frac{O_2P}{O_1P} \quad \dots(iii)$$

We see that the angular velocity ratio is inversely proportional to the ratio of the distance of  $P$  from the centres



**Fig. 28.7.** Law of gearing.

## 1028 ■ A Textbook of Machine Design

$O_1$  and  $O_2$ , or the common normal to the two surfaces at the point of contact  $Q$  intersects the line of centres at point  $P$  which divides the centre distance inversely as the ratio of angular velocities.



*Aircraft landing gear is especially designed to absorb shock and energy when an aircraft lands, and then release gradually.*

Therefore, in order to have a constant angular velocity ratio for all positions of the wheels,  $P$  must be the fixed point (called pitch point) for the two wheels. In other words, ***the common normal at the point of contact between a pair of teeth must always pass through the pitch point.*** This is fundamental condition which must be satisfied while designing the profiles for the teeth of gear wheels. It is also known as ***law of gearing.***

**Notes : 1.** The above condition is fulfilled by teeth of involute form, provided that the root circles from which the profiles are generated are tangential to the common normal.

**2.** If the shape of one tooth profile is arbitrary chosen and another tooth is designed to satisfy the above condition, then the second tooth is said to be **conjugate** to the first. The conjugate teeth are not in common use because of difficulty in manufacture and cost of production.

**3.** If  $D_1$  and  $D_2$  are pitch circle diameters of wheel 1 and 2 having teeth  $T_1$  and  $T_2$  respectively, then velocity ratio,

$$\frac{\omega_1}{\omega_2} = \frac{O_2P}{O_1P} = \frac{D_2}{D_1} = \frac{T_2}{T_1}$$



*Gear trains inside a mechanical watch*



### 28.7 Forms of Teeth


We have discussed in Art. 28.6 (Note 2) that conjugate teeth are not in common use. Therefore, in actual practice, following are the two types of teeth commonly used.

1. Cycloidal teeth ; and
2. Involute teeth.

We shall discuss both the above mentioned types of teeth in the following articles. Both these forms of teeth satisfy the condition as explained in Art. 28.6.

### 28.8 Cycloidal Teeth

A *cycloid* is the curve traced by a point on the circumference of a circle which rolls without slipping on a fixed straight line. When a circle rolls without slipping on the outside of a fixed circle, the curve traced by a point on the circumference of a circle is known as *epicycloid*. On the other hand, if a circle rolls without slipping on the inside of a fixed circle, then the curve traced by a point on the circumference of a circle is called *hypocycloid*.



**Fig. 28.8.** Construction of cycloidal teeth of a gear.

In Fig. 28.8 (a), the fixed line or pitch line of a rack is shown. When the circle C rolls without slipping above the pitch line in the direction as indicated in Fig. 28.8 (a), then the point P on the circle traces the epicycloid PA. This represents the face of the cycloidal tooth profile. When the circle D rolls without slipping below the pitch line, then the point P on the circle D traces hypocycloid PB which represents the flank of the cycloidal tooth. The profile BPA is one side of the cycloidal rack tooth. Similarly, the two curves P'A' and P'B' forming the opposite side of the tooth profile are traced by the point P' when the circles C and D roll in the opposite directions.

In the similar way, the cycloidal teeth of a gear may be constructed as shown in Fig. 28.8 (b). The circle C is rolled without slipping on the outside of the pitch circle and the point P on the circle C traces epicycloid PA, which represents the face of the cycloidal tooth. The circle D is rolled on the inside of pitch circle and the point P on the circle D traces hypocycloid PB, which represents the flank of the tooth profile. The profile BPA is one side of the cycloidal tooth. The opposite side of the tooth is traced as explained above.

The construction of the two mating cycloidal teeth is shown in Fig. 28.9. A point on the circle D will trace the flank of the tooth  $T_1$  when circle D rolls without slipping on the inside of pitch circle of wheel 1 and face of tooth  $T_2$  when the circle D rolls without slipping on the outside of pitch circle of wheel 2. Similarly, a point on the circle C will trace the face of tooth  $T_1$  and flank of tooth  $T_2$ . The rolling circles C and D may have unequal diameters, but if several wheels are to be interchangeable, they must have rolling circles of equal diameters.




Fig. 28.9. Construction of two mating cycloidal teeth.

A little consideration will show that the common normal  $XX$  at the point of contact between two cycloidal teeth always passes through the pitch point, which is the fundamental condition for a constant velocity ratio.

### 28.9 Involute Teeth

An involute of a circle is a plane curve generated by a point on a tangent, which rolls on the circle without slipping or by a point on a taut string which is unwrapped from a reel as shown in Fig. 28.10 (a). In connection with toothed wheels, the circle is known as base circle. The involute is traced as follows :

Let  $A$  be the starting point of the involute. The base circle is divided into equal number of parts e.g.  $AP_1, P_1P_2, P_2P_3$  etc. The tangents at  $P_1, P_2, P_3$  etc., are drawn and the lengths  $P_1A_1, P_2A_2, P_3A_3$  equal to the arcs  $AP_1, AP_2$  and  $AP_3$  are set off. Joining the points  $A, A_1, A_2, A_3$  etc., we obtain the involute curve  $AR$ . A little consideration will show that at any instant  $A_3$ , the tangent  $A_3T$  to the involute is perpendicular to  $P_3A_3$  and  $P_3A_3$  is the normal to the involute. In other words, normal at any point of an involute is a tangent to the circle.

Now, let  $O_1$  and  $O_2$  be the fixed centres of the two base circles as shown in Fig. 28.10(b). Let the corresponding involutes  $AB$  and  $A'B'$  be in contact at point  $Q$ .  $MQ$  and  $NQ$  are normals to the involute at  $Q$  and are tangents to base circles. Since the normal for an involute at a given point is the tangent drawn from that point to the base circle, therefore the common normal  $MN$  at  $Q$  is also the common tangent to the two base circles. We see that the common normal  $MN$  intersects the line of centres  $O_1O_2$  at the fixed point  $P$  (called pitch point). Therefore the involute teeth satisfy the fundamental condition of constant velocity ratio.



The clock built by Galileo used gears.

From similar triangles  $O_2 NP$  and  $O_1 MP$ ,

$$\frac{O_1 M}{O_2 N} = \frac{O_1 P}{O_2 P} = \frac{\omega_2}{\omega_1} \quad \dots(i)$$

which determines the ratio of the radii of the two base circles. The radii of the base circles is given by

$$O_1 M = O_1 P \cos \phi, \text{ and } O_2 N = O_2 P \cos \phi$$

where  $\phi$  is the pressure angle or the angle of obliquity.

Also the centre distance between the base circles

$$= O_1 P + O_2 P = \frac{O_1 M}{\cos \phi} + \frac{O_2 N}{\cos \phi} = \frac{O_1 M + O_2 N}{\cos \phi}$$




Fig. 28.10. Construction of involute teeth.

A little consideration will show, that if the centre distance is changed, then the radii of pitch circles also changes. But their ratio remains unchanged, because it is equal to the ratio of the two radii of the base circles [See equation (i)]. The common normal, at the point of contact, still passes through the pitch point. As a result of this, the wheel continues to work correctly\*. However, the pressure angle increases with the increase in centre distance.

### 28.10 Comparison Between Involute and Cycloidal Gears

In actual practice, the involute gears are more commonly used as compared to cycloidal gears, due to the following advantages :

#### Advantages of involute gears

Following are the advantages of involute gears :

1. The most important advantage of the involute gears is that the centre distance for a pair of involute gears can be varied within limits without changing the velocity ratio. This is not true for cycloidal gears which requires exact centre distance to be maintained.
2. In involute gears, the pressure angle, from the start of the engagement of teeth to the end of the engagement, remains constant. It is necessary for smooth running and less wear of gears. But in cycloidal gears, the pressure angle is maximum at the beginning of engagement, reduces to zero at pitch point, starts increasing and again becomes maximum at the end of engagement. This results in less smooth running of gears.
3. The face and flank of involute teeth are generated by a single curve whereas in cycloidal gears, double curves (*i.e.* epicycloid and hypocycloid) are required for the face and flank respectively.

\* It is not the case with cycloidal teeth.

Thus the involute teeth are easy to manufacture than cycloidal teeth. In involute system, the basic rack has straight teeth and the same can be cut with simple tools.

**Note :** The only disadvantage of the involute teeth is that the interference occurs (Refer Art. 28.13) with pinions having smaller number of teeth. This may be avoided by altering the heights of addendum and dedendum of the mating teeth or the angle of obliquity of the teeth.

**Advantages of cycloidal gears**

Following are the advantages of cycloidal gears :

1. Since the cycloidal teeth have wider flanks, therefore the cycloidal gears are stronger than the involute gears for the same pitch. Due to this reason, the cycloidal teeth are preferred specially for cast teeth.
2. In cycloidal gears, the contact takes place between a convex flank and concave surface, whereas in involute gears, the convex surfaces are in contact. This condition results in less wear in cycloidal gears as compared to involute gears. However the difference in wear is negligible.
3. In cycloidal gears, the interference does not occur at all. Though there are advantages of cycloidal gears but they are outweighed by the greater simplicity and flexibility of the involute gears.

**28.11 Systems of Gear Teeth**

The following four systems of gear teeth are commonly used in practice.

1.  $14\frac{1}{2}^\circ$  Composite system, 2.  $14\frac{1}{2}^\circ$  Full depth involute system, 3.  $20^\circ$  Full depth involute system, and 4.  $20^\circ$  Stub involute system.

The  $14\frac{1}{2}^\circ$  **composite system** is used for general purpose gears. It is stronger but has no interchangeability. The tooth profile of this system has cycloidal curves at the top and bottom and involute curve at the middle portion. The teeth are produced by formed milling cutters or hobs. The tooth profile of the  $14\frac{1}{2}^\circ$  **full depth involute system** was developed for use with gear hobs for spur and helical gears.

The tooth profile of the  $20^\circ$  **full depth involute system** may be cut by hobs. The increase of the pressure angle from  $14\frac{1}{2}^\circ$  to  $20^\circ$  results in a stronger tooth, because the tooth acting as a beam is wider at the base. The  $20^\circ$  **stub involute system** has a strong tooth to take heavy loads.

**28.12 Standard Proportions of Gear Systems**

The following table shows the standard proportions in module (*m*) for the four gear systems as discussed in the previous article.

**Table 28.1. Standard proportions of gear systems.**


S. No.	Particulars	$14\frac{1}{2}^\circ$ composite or full depth involute system	$20^\circ$ full depth involute system	$20^\circ$ stub involute system
1.	Addendum	1 <i>m</i>	1 <i>m</i>	0.8 <i>m</i>
2.	Dedendum	1.25 <i>m</i>	1.25 <i>m</i>	1 <i>m</i>
3.	Working depth	2 <i>m</i>	2 <i>m</i>	1.60 <i>m</i>
4.	Minimum total depth	2.25 <i>m</i>	2.25 <i>m</i>	1.80 <i>m</i>
5.	Tooth thickness	1.5708 <i>m</i>	1.5708 <i>m</i>	1.5708 <i>m</i>
6.	Minimum clearance	0.25 <i>m</i>	0.25 <i>m</i>	0.2 <i>m</i>
7.	Fillet radius at root	0.4 <i>m</i>	0.4 <i>m</i>	0.4 <i>m</i>

### 28.13 Interference in Involute Gears

A pinion gearing with a wheel is shown in Fig. 28.11.  $MN$  is the common tangent to the base circles and  $KL$  is the path of contact between the two mating teeth. A little consideration will show, that if the radius of the addendum circle of pinion is increased to  $O_1N$ , the point of contact  $L$  will move from  $L$  to  $N$ . When this radius is further increased, the point of contact  $L$  will be on the inside of base circle of wheel and not on the involute profile of tooth on wheel. The tip of tooth on the pinion will then undercut the tooth on the wheel at the root and remove part of the involute profile of tooth on the wheel. This effect is known as **interference** and occurs when the teeth are being cut. In brief, *the phenomenon when the tip of a tooth undercuts the root on its mating gear is known as interference.*



A drilling machine drilling holes for lamp retaining screws



**Fig. 28.11.** Interference in involute gears.

Similarly, if the radius of the addendum circle of the wheel increases beyond  $O_2M$ , then the tip of tooth on wheel will cause interference with the tooth on pinion. The points  $M$  and  $N$  are called **interference points**. Obviously interference may be avoided if the path of contact does not extend beyond interference points. The limiting value of the radius of the addendum circle of the pinion is  $O_1N$  and of the wheel is  $O_2M$ .

From the above discussion, we conclude that the interference may only be avoided, if the point of contact between the two teeth is always on the involute profiles of both the teeth. In other words, **interference may only be prevented, if the addendum circles of the two mating gears cut the common tangent to the base circles between the points of tangency.**

## 1034 ■ A Textbook of Machine Design

**Note :** In order to avoid interference, the limiting value of the radius of the addendum circle of the pinion ( $O_1 N$ ) and of the wheel ( $O_2 M$ ), may be obtained as follows :

From Fig. 28.11, we see that

$$O_1 N = \sqrt{(O_1 M)^2 + (MN)^2} = \sqrt{(r_b)^2 + [(r + R) \sin \phi]^2}$$

where

$$r_b = \text{Radius of base circle of the pinion} = O_1 P \cos \phi = r \cos \phi$$

Similarly

$$O_2 M = \sqrt{(O_2 N)^2 + (MN)^2} = \sqrt{(R_b)^2 + [(r + R) \sin \phi]^2}$$

where

$$R_b = \text{Radius of base circle of the wheel} = O_2 P \cos \phi = R \cos \phi$$

### 28.14 Minimum Number of Teeth on the Pinion in Order to Avoid Interference

We have seen in the previous article that the interference may only be avoided, if the point of contact between the two teeth is always on the involute profiles of both the teeth. The minimum number of teeth on the pinion which will mesh with any gear (also rack) without interference are given in the following table.

**Table 28.2. Minimum number of teeth on the pinion in order to avoid interference.**

S. No.	Systems of gear teeth	Minimum number of teeth on the pinion
1.	14½° Composite	12
2.	14½° Full depth involute	32
3.	20° Full depth involute	18
4.	20° Stub involute	14

The number of teeth on the pinion ( $T_p$ ) in order to avoid interference may be obtained from the following relation :

$$T_p = \frac{2 A_w}{G \left[ \sqrt{1 + \frac{1}{G} \left( \frac{1}{G} + 2 \right) \sin^2 \phi} - 1 \right]}$$

where

$A_w$  = Fraction by which the standard addendum for the wheel should be multiplied,

$$G = \text{Gear ratio or velocity ratio} = T_G / T_P = D_G / D_P,$$

$\phi$  = Pressure angle or angle of obliquity.

### 28.15 Gear Materials

The material used for the manufacture of gears depends upon the strength and service conditions like wear, noise etc. The gears may be manufactured from metallic or non-metallic materials. The metallic gears with cut teeth are commercially obtainable in cast iron, steel and bronze. The non-metallic materials like wood, rawhide, compressed paper and synthetic resins like nylon are used for gears, especially for reducing noise.

The cast iron is widely used for the manufacture of gears due to its good wearing properties, excellent machinability and ease of producing complicated shapes by casting method. The cast iron gears with cut teeth may be employed, where smooth action is not important.

The steel is used for high strength gears and steel may be plain carbon steel or alloy steel. The steel gears are usually heat treated in order to combine properly the toughness and tooth hardness.



The phosphor bronze is widely used for worm gears in order to reduce wear of the worms which will be excessive with cast iron or steel. The following table shows the properties of commonly used gear materials.

**Table 28.3. Properties of commonly used gear materials.**

<i>Material</i> (1)	<i>Condition</i> (2)	<i>Brinell hardness number</i> (3)	<i>Minimum tensile strength (N/mm<sup>2</sup>)</i> (4)
<i>Malleable cast iron</i>			
(a) White heart castings, Grade B	—	217 max.	280
(b) Black heart castings, Grade B	—	149 max.	320
<i>Cast iron</i>			
(a) Grade 20	As cast	179 min.	200
(b) Grade 25	As cast	197 min.	250
(c) Grade 35	As cast	207 min.	250
(d) Grade 35	Heat treated	300 min.	350
<i>Cast steel</i>	—	145	550
<i>Carbon steel</i>			
(a) 0.3% carbon	Normalised	143	500
(b) 0.3% carbon	Hardened and tempered	152	600
(c) 0.4% carbon	Normalised	152	580
(d) 0.4% carbon	Hardened and tempered	179	600
(e) 0.35% carbon	Normalised	201	720
(f) 0.55% carbon	Hardened and tempered	223	700
<i>Carbon chromium steel</i>			
(a) 0.4% carbon	Hardened and tempered	229	800
(b) 0.55% carbon	”	225	900
<i>Carbon manganese steel</i>			
(a) 0.27% carbon	Hardened and tempered	170	600
(b) 0.37% carbon	”	201	700
<i>Manganese molybdenum steel</i>			
(a) 35 Mn 2 Mo 28	Hardened and tempered	201	700
(b) 35 Mn 2 Mo 45	”	229	800
<i>Chromium molybdenum steel</i>			
(a) 40 Cr 1 Mo 28	Hardened and tempered	201	700
(b) 40 Cr 1 Mo 60	”	248	900

## 1036 ■ A Textbook of Machine Design

(1)	(2)	(3)	(4)
<i>Nickel steel</i>			
40 Ni 3	”	229	800
<i>Nickel chromium steel</i>			
30 Ni 4 Cr 1	”	444	1540
<i>Nickel chromium molybdenum steel</i>	Hardness and		
40 Ni 2 Cr 1 Mo 28	tempered	255	900
<i>Surface hardened steel</i>			
(a) 0.4% carbon steel	—	145 (core) 460 (case)	551
(b) 0.55% carbon steel	—	200 (core) 520 (case)	708
(c) 0.55% carbon chromium steel	—	250 (core) 500 (case)	866
(d) 1% chromium steel	—	500 (case)	708
(e) 3% nickel steel	—	200 (core) 300 (case)	708
<i>Case hardened steel</i>			
(a) 0.12 to 0.22% carbon	—	650 (case)	504
(b) 3% nickel	—	200 (core) 600 (case)	708
(c) 5% nickel steel	—	250 (core) 600 (case)	866
<i>Phosphor bronze castings</i>	Sand cast	60 min.	160
	Chill cast	70 min.	240
	Centrifugal cast	90	260

### 28.16 Design Considerations for a Gear Drive

In the design of a gear drive, the following data is usually given :

1. The power to be transmitted.
2. The speed of the driving gear,
3. The speed of the driven gear or the velocity ratio, and
4. The centre distance.

The following requirements must be met in the design of a gear drive :

- (a) The gear teeth should have sufficient strength so that they will not fail under static loading or dynamic loading during normal running conditions.
- (b) The gear teeth should have wear characteristics so that their life is satisfactory.
- (c) The use of space and material should be economical.
- (d) The alignment of the gears and deflections of the shafts must be considered because they effect on the performance of the gears.
- (e) The lubrication of the gears must be satisfactory.

### 28.17 Beam Strength of Gear Teeth – Lewis Equation

The beam strength of gear teeth is determined from an equation (known as \*Lewis equation) and the load carrying ability of the toothed gears as determined by this equation gives satisfactory results. In the investigation, Lewis assumed that as the load is being transmitted from one gear to another, it is all given and taken by one tooth, because it is not always safe to assume that the load is distributed among several teeth. When contact begins, the load is assumed to be at the end of the driven teeth and as contact ceases, it is at the end of the driving teeth. This may not be true when the number of teeth in a pair of mating gears is large, because the load may be distributed among several teeth. But it is almost certain that at some time during the contact of teeth, the proper distribution of load does not exist and that one tooth must transmit the full load. In any pair of gears having unlike number of teeth, the gear which have the fewer teeth (*i.e.* pinion) will be the weaker, because the tendency toward undercutting of the teeth becomes more pronounced in gears as the number of teeth becomes smaller.

Consider each tooth as a cantilever beam loaded by a normal load ( $W_N$ ) as shown in Fig. 28.12. It is resolved into two components *i.e.* tangential component ( $W_T$ ) and radial component ( $W_R$ ) acting perpendicular and parallel to the centre line of the tooth respectively. The tangential component ( $W_T$ ) induces a bending stress which tends to break the tooth. The radial component ( $W_R$ ) induces a compressive stress of relatively small magnitude, therefore its effect on the tooth may be neglected. Hence, the bending stress is used as the basis for design calculations. The critical section or the section of maximum bending stress may be obtained by drawing a parabola through A and tangential to the tooth curves at B and C. This parabola, as shown dotted in Fig. 28.12, outlines a beam of uniform strength, *i.e.* if the teeth are shaped like a parabola, it will have the same stress at all the sections. But the tooth is larger than the parabola at every section except BC. We therefore, conclude that the section BC is the section of maximum stress or the critical section. The maximum value of the bending stress (or the permissible working stress), at the section BC is given by




Fig. 28.12. Tooth of a gear.

$$\sigma_w = M.y / I \quad \dots(i)$$

where

$M$  = Maximum bending moment at the critical section  $BC = W_T \times h$ ,

$W_T$  = Tangential load acting at the tooth,

$h$  = Length of the tooth,

$y$  = Half the thickness of the tooth ( $t$ ) at critical section  $BC = t/2$ ,

$I$  = Moment of inertia about the centre line of the tooth  $= b.t^3/12$ ,

$b$  = Width of gear face.

Substituting the values for  $M$ ,  $y$  and  $I$  in equation (i), we get

$$\sigma_w = \frac{(W_T \times h) t / 2}{b.t^3 / 12} = \frac{(W_T \times h) \times 6}{b.t^2}$$

or

$$W_T = \sigma_w \times b \times t^2 / 6 h$$

In this expression,  $t$  and  $h$  are variables depending upon the size of the tooth (*i.e.* the circular pitch) and its profile.

\* In 1892, Wilfred Lewis investigated for the strength of gear teeth. He derived an equation which is now extensively used by industry in determining the size and proportions of the gear.

## 1038 ■ A Textbook of Machine Design

Let  $t = x \times p_c$ , and  $h = k \times p_c$ ; where  $x$  and  $k$  are constants.

$$\therefore W_T = \sigma_w \times b \times \frac{x^2 \cdot p_c^2}{6k \cdot p_c} = \sigma_w \times b \times p_c \times \frac{x^2}{6k}$$

Substituting  $x^2 / 6k = y$ , another constant, we have

$$W_T = \sigma_w \cdot b \cdot p_c \cdot y = \sigma_w \cdot b \cdot \pi m \cdot y \quad \dots (\because p_c = \pi m)$$


The quantity  $y$  is known as **Lewis form factor** or **tooth form factor** and  $W_T$  (which is the tangential load acting at the tooth) is called the **beam strength of the tooth**.

Since  $y = \frac{x^2}{6k} = \frac{t^2}{(p_c)^2} \times \frac{p_c}{6h} = \frac{t^2}{6h \cdot p_c}$ , therefore in order to find the value of  $y$ , the quantities  $t$ ,  $h$  and  $p_c$  may be determined analytically or measured from the drawing similar to Fig. 28.12. It may be noted that if the gear is enlarged, the distances  $t$ ,  $h$  and  $p_c$  will each increase proportionately. Therefore the value of  $y$  will remain unchanged. A little consideration will show that the value of  $y$  is independent of the size of the tooth and depends only on the number of teeth on a gear and the system of teeth. The value of  $y$  in terms of the number of teeth may be expressed as follows :

$$\begin{aligned} y &= 0.124 - \frac{0.684}{T}, \text{ for } 14\frac{1}{2}^\circ \text{ composite and full depth involute system.} \\ &= 0.154 - \frac{0.912}{T}, \text{ for } 20^\circ \text{ full depth involute system.} \\ &= 0.175 - \frac{0.841}{T}, \text{ for } 20^\circ \text{ stub system.} \end{aligned}$$

### 28.18 Permissible Working Stress for Gear Teeth in the Lewis Equation

The permissible working stress ( $\sigma_w$ ) in the Lewis equation depends upon the material for which an allowable static stress ( $\sigma_s$ ) may be determined. The **allowable static stress** is the stress at the



Bicycle gear mechanism switches the chain between different sized sprockets at the pedals and on the back wheel. Going up hill, a small front and a large rear sprocket are selected to reduce the push required for the rider. On the level, a large front and small rear sprocket are used to prevent the rider having to pedal too fast.

elastic limit of the material. It is also called the *basic stress*. In order to account for the dynamic effects which become more severe as the pitch line velocity increases, the value of  $\sigma_w$  is reduced. According to the Barth formula, the permissible working stress,

$$\sigma_w = \sigma_o \times C_v$$

where

$\sigma_o$  = Allowable static stress, and

$C_v$  = Velocity factor.

The values of the velocity factor ( $C_v$ ) are given as follows :

$$C_v = \frac{3}{3 + v}, \text{ for ordinary cut gears operating at velocities upto 12.5 m / s.}$$

$$= \frac{4.5}{4.5 + v}, \text{ for carefully cut gears operating at velocities upto 12.5 m/s.}$$

$$= \frac{6}{6 + v}, \text{ for very accurately cut and ground metallic gears operating at velocities upto 20 m / s.}$$

$$= \frac{0.75}{0.75 + \sqrt{v}}, \text{ for precision gears cut with high accuracy and operating at velocities upto 20 m / s.}$$

$$= \left( \frac{0.75}{1 + v} \right) + 0.25, \text{ for non-metallic gears.}$$

In the above expressions,  $v$  is the pitch line velocity in metres per second.

The following table shows the values of allowable static stresses for the different gear materials.

**Table 28.4. Values of allowable static stress.**

Material	Allowable static stress ( $\sigma_o$ ) MPa or N/mm <sup>2</sup>
Cast iron, ordinary	56
Cast iron, medium grade	70
Cast iron, highest grade	105
Cast steel, untreated	140
Cast steel, heat treated	196
Forged carbon steel-case hardened	126
Forged carbon steel-untreated	140 to 210
Forged carbon steel-heat treated	210 to 245
Alloy steel-case hardened	350
Alloy steel-heat treated	455 to 472
Phosphor bronze	84
<i>Non-metallic materials</i>	
Rawhide, fabroil	42
Bakelite, Micarta, Celoron	56

**Note :** The allowable static stress ( $\sigma_o$ ) for steel gears is approximately one-third of the ultimate tensile strength ( $\sigma_u$ ) i.e.  $\sigma_o = \sigma_u / 3$ .

28.19 Dynamic Tooth Load

In the previous article, the velocity factor was used to make approximate allowance for the effect of dynamic loading. The dynamic loads are due to the following reasons :

1. Inaccuracies of tooth spacing,
2. Irregularities in tooth profiles, and
3. Deflections of teeth under load.

A closer approximation to the actual conditions may be made by the use of equations based on extensive series of tests, as follows :

$$W_D = W_T + W_I$$

where  $W_D$  = Total dynamic load,  
 $W_T$  = Steady load due to transmitted torque, and  
 $W_I$  = Increment load due to dynamic action.

The increment load ( $W_I$ ) depends upon the pitch line velocity, the face width, material of the gears, the accuracy of cut and the tangential load. For average conditions, the dynamic load is determined by using the following Buckingham equation, *i.e.*

$$W_D = W_T + W_I = W_T + \frac{21 v (b.C + W_T)}{21 v + \sqrt{b.C + W_T}} \quad \dots(i)$$

where  $W_D$  = Total dynamic load in newtons,  
 $W_T$  = Steady transmitted load in newtons,  
 $v$  = Pitch line velocity in m/s,  
 $b$  = Face width of gears in mm, and  
 $C$  = A deformation or dynamic factor in N/mm.

A deformation factor ( $C$ ) depends upon the error in action between teeth, the class of cut of the gears, the tooth form and the material of the gears. The following table shows the values of deformation factor ( $C$ ) for checking the dynamic load on gears.

**Table 28.5. Values of deformation factor (C).**

Material		Involute tooth form	Values of deformation factor (C) in N-mm				
Pinion	Gear		Tooth error in action (e) in mm				
			0.01	0.02	0.04	0.06	0.08
Cast iron	Cast iron	14½°	55	110	220	330	440
Steel	Cast iron		76	152	304	456	608
Steel	Steel		110	220	440	660	880
Cast iron	Cast iron	20° full depth	57	114	228	342	456
Steel	Cast iron		79	158	316	474	632
Steel	Steel		114	228	456	684	912
Cast iron	Cast iron	20° stub	59	118	236	354	472
Steel	Cast iron		81	162	324	486	648
Steel	Steel		119	238	476	714	952

The value of  $C$  in N/mm may be determined by using the following relation :

$$C = \frac{K.e}{\frac{1}{E_p} + \frac{1}{E_G}} \quad \dots (ii)$$



where

- $K$  = A factor depending upon the form of the teeth.
  - = 0.107, for  $14\frac{1}{2}^\circ$  full depth involute system.
  - = 0.111, for  $20^\circ$  full depth involute system.
  - = 0.115 for  $20^\circ$  stub system.
- $E_p$  = Young's modulus for the material of the pinion in  $N/mm^2$ .
- $E_G$  = Young's modulus for the material of gear in  $N/mm^2$ .
- $e$  = Tooth error action in mm.

The maximum allowable tooth error in action ( $e$ ) depends upon the pitch line velocity ( $v$ ) and the class of cut of the gears. The following tables show the values of tooth errors in action ( $e$ ) for the different values of pitch line velocities and modules.

**Table 28.6. Values of maximum allowable tooth error in action ( $e$ ) versus pitch line velocity, for well cut commercial gears.**

Pitch line velocity ( $v$ ) m/s	Tooth error in action ( $e$ ) mm	Pitch line velocity ( $v$ ) m/s	Tooth error in action ( $e$ ) mm	Pitch line velocity ( $v$ ) m/s	Tooth error in action ( $e$ ) mm
1.25	0.0925	8.75	0.0425	16.25	0.0200
2.5	0.0800	10	0.0375	17.5	0.0175
3.75	0.0700	11.25	0.0325	20	0.0150
5	0.0600	12.5	0.0300	22.5	0.0150
6.25	0.0525	13.75	0.0250	25 and over	0.0125
7.5	0.0475	15	0.0225		

**Table 28.7. Values of tooth error in action ( $e$ ) versus module.**

Module ( $m$ ) in mm	Tooth error in action ( $e$ ) in mm		
	First class commercial gears	Carefully cut gears	Precision gears
Upto 4	0.051	0.025	0.0125
5	0.055	0.028	0.015
6	0.065	0.032	0.017
7	0.071	0.035	0.0186
8	0.078	0.0386	0.0198
9	0.085	0.042	0.021
10	0.089	0.0445	0.023
12	0.097	0.0487	0.0243
14	0.104	0.052	0.028
16	0.110	0.055	0.030
18	0.114	0.058	0.032
20	0.117	0.059	0.033

### 28.20 Static Tooth Load

The *static tooth load* (also called *beam strength* or *endurance strength* of the tooth) is obtained by Lewis formula by substituting flexural endurance limit or elastic limit stress ( $\sigma_e$ ) in place of permissible working stress ( $\sigma_w$ ).

∴ Static tooth load or beam strength of the tooth,

$$W_S = \sigma_e \cdot b \cdot p_c \cdot y = \sigma_e \cdot b \cdot \pi m \cdot y$$

The following table shows the values of flexural endurance limit ( $\sigma_e$ ) for different materials.

**Table 28.8. Values of flexural endurance limit.**

Material of pinion and gear	Brinell hardness number (B.H.N.)	Flexural endurance limit ( $\sigma_e$ ) in MPa
Grey cast iron	160	84
Semi-steel	200	126
Phosphor bronze	100	168
Steel	150	252
	200	350
	240	420
	280	490
	300	525
	320	560
	350	595
	360	630
	400 and above	700

For safety, against tooth breakage, the static tooth load ( $W_S$ ) should be greater than the dynamic load ( $W_D$ ). Buckingham suggests the following relationship between  $W_S$  and  $W_D$ .

For steady loads,  $W_S \geq 1.25 W_D$

For pulsating loads,  $W_S \geq 1.35 W_D$

For shock loads,  $W_S \geq 1.5 W_D$

**Note :** For steel, the flexural endurance limit ( $\sigma_e$ ) may be obtained by using the following relation :

$$\sigma_e = 1.75 \times \text{B.H.N. (in MPa)}$$

### 28.21 Wear Tooth Load

The maximum load that gear teeth can carry, without premature wear, depends upon the radii of curvature of the tooth profiles and on the elasticity and surface fatigue limits of the materials. The maximum or the limiting load for satisfactory wear of gear teeth, is obtained by using the following Buckingham equation, *i.e.*

$$W_w = D_p \cdot b \cdot Q \cdot K$$

where

$W_w$  = Maximum or limiting load for wear in newtons,

$D_p$  = Pitch circle diameter of the pinion in mm,

$b$  = Face width of the pinion in mm,

$Q$  = Ratio factor

$$= \frac{2 \times V.R.}{V.R. + 1} = \frac{2T_G}{T_G + T_P}, \text{ for external gears}$$

$$= \frac{2 \times V.R.}{V.R. - 1} = \frac{2T_G}{T_G - T_P}, \text{ for internal gears.}$$

$V.R.$  = Velocity ratio =  $T_G / T_P$ ,

$K$  = Load-stress factor (also known as material combination factor) in  $\text{N/mm}^2$ .

The load stress factor depends upon the maximum fatigue limit of compressive stress, the pressure angle and the modulus of elasticity of the materials of the gears. According to Buckingham, the load stress factor is given by the following relation :

$$K = \frac{(\sigma_{es})^2 \sin \phi}{1.4} \left( \frac{1}{E_p} + \frac{1}{E_G} \right)$$

where

$\sigma_{es}$  = Surface endurance limit in MPa or N/mm<sup>2</sup>,

$\phi$  = Pressure angle,

$E_p$  = Young's modulus for the material of the pinion in N/mm<sup>2</sup>, and

$E_G$  = Young's modulus for the material of the gear in N/mm<sup>2</sup>.

The values of surface endurance limit ( $\sigma_{es}$ ) are given in the following table.

**Table 28.9. Values of surface endurance limit.**

Material of pinion and gear	Brinell hardness number (B.H.N.)	Surface endurance limit ( $\sigma_{es}$ ) in N/mm <sup>2</sup>
Grey cast iron	160	630
Semi-steel	200	630
Phosphor bronze	100	630
Steel	150	350
	200	490
	240	616
	280	721
	300	770
	320	826
	350	910
	400	1050



## 1044 ■ A Textbook of Machine Design

**Notes : 1.** The surface endurance limit for steel may be obtained from the following equation :

$$\sigma_{es} = (2.8 \times \text{B.H.N.} - 70) \text{ N/mm}^2$$

**2.** The maximum limiting wear load ( $W_w$ ) must be greater than the dynamic load ( $W_D$ ).

### 28.22 Causes of Gear Tooth Failure

The different modes of failure of gear teeth and their possible remedies to avoid the failure, are as follows :

**1. Bending failure.** Every gear tooth acts as a cantilever. If the total repetitive dynamic load acting on the gear tooth is greater than the beam strength of the gear tooth, then the gear tooth will fail in bending, *i.e.* the gear tooth will break.

In order to avoid such failure, the module and face width of the gear is adjusted so that the beam strength is greater than the dynamic load.

**2. Pitting.** It is the surface fatigue failure which occurs due to many repetition of Hertz contact stresses. The failure occurs when the surface contact stresses are higher than the endurance limit of the material. The failure starts with the formation of pits which continue to grow resulting in the rupture of the tooth surface.

In order to avoid the pitting, the dynamic load between the gear tooth should be less than the wear strength of the gear tooth.

**3. Scoring.** The excessive heat is generated when there is an excessive surface pressure, high speed or supply of lubricant fails. It is a stick-slip phenomenon in which alternate shearing and welding takes place rapidly at high spots.

This type of failure can be avoided by properly designing the parameters such as speed, pressure and proper flow of the lubricant, so that the temperature at the rubbing faces is within the permissible limits.

**4. Abrasive wear.** The foreign particles in the lubricants such as dirt, dust or burr enter between the tooth and damage the form of tooth. This type of failure can be avoided by providing filters for the lubricating oil or by using high viscosity lubricant oil which enables the formation of thicker oil film and hence permits easy passage of such particles without damaging the gear surface.

**5. Corrosive wear.** The corrosion of the tooth surfaces is mainly caused due to the presence of corrosive elements such as additives present in the lubricating oils. In order to avoid this type of wear, proper anti-corrosive additives should be used.

### 28.23 Design Procedure for Spur Gears

In order to design spur gears, the following procedure may be followed :

**1.** First of all, the design tangential tooth load is obtained from the power transmitted and the pitch line velocity by using the following relation :

$$W_T = \frac{P}{v} \times C_S \quad \dots(i)$$

where

$W_T$  = Permissible tangential tooth load in newtons,

$P$  = Power transmitted in watts,

$$*v = \text{Pitch line velocity in m / s} = \frac{\pi D N}{60},$$

$D$  = Pitch circle diameter in metres,

\* We know that circular pitch,

$$p_c = \pi D / T = \pi m \quad \dots(\because m = D / T)$$

$$\therefore D = m.T$$

Thus, the pitch line velocity may also be obtained by using the following relation, *i.e.*

$$v = \frac{\pi D.N}{60} = \frac{\pi m.T.N}{60} = \frac{p_c.T.N}{60}$$

where

$m$  = Module in metres, and

$T$  = Number of teeth.

$N$  = Speed in r.p.m., and  
 $C_s$  = Service factor.

The following table shows the values of service factor for different types of loads :

**Table 28.10. Values of service factor.**

Type of load	Type of service		
	Intermittent or 3 hours per day	8-10 hours per day	Continuous 24 hours per day
Steady	0.8	1.00	1.25
Light shock	1.00	1.25	1.54
Medium shock	1.25	1.54	1.80
Heavy shock	1.54	1.80	2.00

**Note :** The above values for service factor are for enclosed well lubricated gears. In case of non-enclosed and grease lubricated gears, the values given in the above table should be divided by 0.65.

2. Apply the Lewis equation as follows :

$$W_T = \sigma_w \cdot b \cdot p_c \cdot y = \sigma_w \cdot b \cdot \pi m \cdot y$$

$$= (\sigma_o \cdot C_v) b \cdot \pi m \cdot y \quad \dots (\because \sigma_w = \sigma_o \cdot C_v)$$

**Notes :** (i) The Lewis equation is applied only to the weaker of the two wheels (*i.e.* pinion or gear).

(ii) When both the pinion and the gear are made of the same material, then pinion is the weaker.

(iii) When the pinion and the gear are made of different materials, then the product of  $(\sigma_w \times y)$  or  $(\sigma_o \times y)$  is the \*deciding factor. The Lewis equation is used to that wheel for which  $(\sigma_w \times y)$  or  $(\sigma_o \times y)$  is less.



A bicycle with changeable gears.

\* We see from the Lewis equation that for a pair of mating gears, the quantities like  $W_T$ ,  $b$ ,  $m$  and  $C_v$  are constant. Therefore  $(\sigma_w \times y)$  or  $(\sigma_o \times y)$  is the only deciding factor.

## 1046 ■ A Textbook of Machine Design

(iv) The product  $(\sigma_w \times y)$  is called **strength factor** of the gear.

(v) The face width ( $b$ ) may be taken as  $3 p_c$  to  $4 p_c$  (or  $9.5 m$  to  $12.5 m$ ) for cut teeth and  $2 p_c$  to  $3 p_c$  (or  $6.5 m$  to  $9.5 m$ ) for cast teeth.

3. Calculate the dynamic load ( $W_D$ ) on the tooth by using Buckingham equation, i.e.

$$\begin{aligned} W_D &= W_T + W_I \\ &= W_T + \frac{21v(b.C + W_T)}{21v + \sqrt{b.C + W_T}} \end{aligned}$$

In calculating the dynamic load ( $W_D$ ), the value of tangential load ( $W_T$ ) may be calculated by neglecting the service factor ( $C_S$ ) i.e.

$$W_T = P / v, \text{ where } P \text{ is in watts and } v \text{ in m / s.}$$

4. Find the static tooth load (i.e. beam strength or the endurance strength of the tooth) by using the relation,

$$W_S = \sigma_e \cdot b \cdot p_c \cdot y = \sigma_e \cdot b \cdot \pi \cdot m \cdot y$$

For safety against breakage,  $W_S$  should be greater than  $W_D$ .

5. Finally, find the wear tooth load by using the relation,

$$W_w = D_p \cdot b \cdot Q \cdot K$$

The wear load ( $W_w$ ) should not be less than the dynamic load ( $W_D$ ).

**Example 28.1.** The following particulars of a single reduction spur gear are given :

Gear ratio = 10 : 1; Distance between centres = 660 mm approximately; Pinion transmits 500 kW at 1800 r.p.m.; Involute teeth of standard proportions (addendum =  $m$ ) with pressure angle of  $22.5^\circ$ ; Permissible normal pressure between teeth = 175 N per mm of width. Find :

1. The nearest standard module if no interference is to occur;
2. The number of teeth on each wheel;
3. The necessary width of the pinion; and
4. The load on the bearings of the wheels due to power transmitted.

**Solution :** Given :  $G = T_G / T_P = D_G / D_P = 10$  ;  $L = 660$  mm ;  $P = 500$  kW =  $500 \times 10^3$  W ;  $N_P = 1800$  r.p.m. ;  $\phi = 22.5^\circ$  ;  $W_N = 175$  N/mm width

**1. Nearest standard module if no interference is to occur**

- Let
- $m$  = Required module,
  - $T_P$  = Number of teeth on the pinion,
  - $T_G$  = Number of teeth on the gear,
  - $D_P$  = Pitch circle diameter of the pinion, and
  - $D_G$  = Pitch circle diameter of the gear.

We know that minimum number of teeth on the pinion in order to avoid interference,

$$\begin{aligned} T_P &= \frac{2A_w}{G \left[ \sqrt{1 + \frac{1}{G} \left( \frac{1}{G} + 2 \right) \sin^2 \phi} - 1 \right]} \\ &= \frac{2 \times 1}{10 \left[ \sqrt{1 + \frac{1}{10} \left( \frac{1}{10} + 2 \right) \sin^2 22.5^\circ} - 1 \right]} = \frac{2}{0.15} = 13.3 \text{ say } 14 \\ &\dots (\because A_w = 1 \text{ module}) \\ \therefore T_G &= G \times T_P = 10 \times 14 = 140 \quad \dots (\because T_G / T_P = 10) \end{aligned}$$